






Backup-Pal®

Supported USB Phones

Updated 08-25-2008

Manufacturer	Tip	Model #				
RIM (Blackberry)	 No Adapter Tip Needed	Curve Series 8300 8310 8320 8330	8800 Series 8800 8820 8830	Charm Series 7100 7100g/i/r/t/v/x	6210 6220 6230 6280 6290	7250 7280 7290 7510 7520
		Pearl Series 8100/8100c 8110 8120 8130	Electron Series 8700c/f/g/r 8703e		6510 7105 7105t 7130c/e/g/v 7210 7230	
Nokia		2000 Series 2865/2865i	6000 Series 6085/6086 6111 6125/6126 6131 6133/6133b 6136 6151 6165i 6267 6170/6170b 6230/6230b 6230i 6233	6234 6235i 6236i 6255/6255i 6256i 6263 6265i 6267 6270 6275i 6280 6288	6300 6301/6301b 6500(Slide) 6555/6555b 6651	7000 Series 7270/7270b 7370 7373 7390 7500 PRISM 7600
		3000 Series 3110 (Classic) 3155/3155i 3500 (Classic) 3555/3555b	XpressMusic Series 5200/5200b 5300/5300b 5310, 5610			
Motorola		KRZR K1 K1m, K3	RIZR Z3 Z6C, Z6M, Z6TV	C350, C350g C353, C353t C650, C975 E380 E398 E790(ROKR E1) E815, E816 E1000, E1070 L71, L72 (SLVR) P280, T300P, T720, T720c, T720g, T720i, C331t C332, C333, C333c, C333g RAZR2 V9 V9m(<small>Verizon & Sprint Only</small>)	V60i, V60ig, V60p, V60s, V60t, V60t Color, V60ti, V60x, V65P, V66, V66i V70, V80, V120, V120c, V120e, V120t, V120x V180, V188, V190, V195, V197, V220, V235 V260, V262, V265, V266, V276, V300 V323i, V325i V330	V360, V361, V365 V400, V500, V505, V525, V535, V540, V547, V551, V551j, V557, V600, V600i, V620, V635, V710, V750, V810, V810c V975, V980 W385 W490 W510 W755
		MOTO Z9 PEBL U6	RAZR Maxx Ve, V3, V3a, V3c, V3i, V3i(Dolce & Gabana), V3m, V3r, V3s, V3t, V3x, V6 maxx V3xx	ROKR E1 (E790) 270c A630, A840, A845 C331g C331t C332, C333, C333c, C333g C341a, C343, C343a		
Samsung		SCH Series SCH-A530 SCH-A570 SCH-A610 SCH-A630 SCH-A645 SCH-A650 SCH-A670 SCH-A850 (<small>InternetPC & LG Cellular Only</small>) SCH-A990 SCH-N330 SCH-U340 SNAP (Alltel Only) SCH-U410 SCH-U470 (JUKE) SCH-U540	SGH Series SGH-A436 SGH-A437 SGH-D307 SGH-D347 SGH-D357 SGH-D407 SGH-D520 SGH-D806 SGH-D807 SGH-D830 SGH-D840 SGH-D900i SGH-D908 SGH-E840	SGH-E870 SGH-E878 SGH-E900 SGH-M610 SGH-P300 SGH-T219 SGH-T229 SGH-T309 SGH-T329 (STRIPe) SGH-T339 SGH-T409 SGH-T429 SGH-T439 SGH-T509 SGH-T519 (TRACE)	SGH-T539 (BEAT) SGH-T609 SGH-T619 SGH-T629 SGH-T719 SGH-T729 (BLAST) SGH-T739 KATALYST SGH-T809 SGH-U100 SGH-U600 SGH-X506 SGH-X507 SGH-X820 SGH-X830	SPH Series SPH-A420 SPH-A560 SPH-A580 SPH-A600 SPH-A620 SPH-A660 SPH-A680 SPH-A700 SPH-A800 SPH-A820 SPH-A840 SPH-A880
		AX Series AX245 AX275 AX300 AX355 AX380 WAVE AX390 AX490/AX490A AX565 MUZIQ AX830 GLIMMER AX4750 AX5000 AX8600	LX Series LX160 LX260 RUMOR LX350 LX550 FUSIC LX570 MUZIQ LX5450 LX5550	PM Series PM225(LX225) PM325(LX325)	VX Series VX3400/VX3450 VX4650 VX4700 VX5200 VX5300 VX5400 VX6000 VX6100 VX7000 VX8000 VX8100 VX8300/VX8350	VX8500 CHOCOLATE VX8550 CHOCOLATE II VX8550A CHOCOLATE II VX8560 CHOCOLATE III VX8600 VX8610 DECOY VX8700 VX8800 VENUS VX9100 enV2 VX9400 VX9700 DARE VX9800 The V VX10000 VOYAGER
LG						

COMING SOON: Support for additional phone Manufacturers and model numbers

contact@backup-pal.com
(888)847-0483
www.backup-pal.com

